

S20A

Automatic/Manual Solvent Spray Gun Cleaner



Check out our
Brief
Training Videos at
www.beccainc.com

Shown with Optional
5 Gallon Cans



BECCA[®]



- **POWERCLEAN** •
PROTECTS AIR PASSAGEWAYS
- **OVERSIZED STAINLESS WORK BASIN** •
SPACIOUS WORK AREA
- **PULSATING FLUID POWER CLEANING** •
FLUSHES AWAY CONTAMINATION

S20A

Automatic/Manual Solvent Spray Gun Cleaner

The New BECCA S20A Automatic Spray Gun Cleaner is designed to meet the challenges of getting solvent spray guns clean quickly....

- Cleans all of the fluid passageways
- Protects air passageways to prevent contamination and corrosion
- Manual & Automatic cleaning features

STANDARD UNIT FEATURES:

- STAINLESS STEEL BASIN w/ COVER - Compact Work Area
- AUTOMATIC HANDS-FREE CYCLE - Free up operator time
- POWERCLEAN™ - Compressed Air Connection Protecting Air Passageways
- PULSATING FLUID - Powerful Cleaning Efficiency
- USED/CLEAN FLUID CONTROL - Superior Cleaning and 50% Solvent Savings
- FLOW BRUSH - Improved Cleaning of dried material
- HI FLOW QD - High Flow Solvent Resistant
- RED POWDER COATED FINISH - Long Maintenance Life
- INPUT AIR FILTER/REGULATOR - Proper System Air Control
- NESHAP COMPLIANT - Meets NESHAP Requirements

OPTIONAL UPGRADES:

- SOLVENTWASH™ CARTRIDGE FILTRATION— Includes a two stage filtration system (75 & 25 Micron Filters)
- FLUID RESERVOIR - 5 Gallon Steel Cans to hold Clean and/or Used Fluid
- DUAL POWERCLEAN KIT - Second Spray Gun Connection in the Wash Basin



Shown with Optional 5 Gallon Steel Cans

Product Specifications:

Dimensions:
41.5"H x 18.5"W x 23.5"L
1054 mm x 470mm x 587 mm

Construction:
Stainless Steel Tank & Pan
Ultra Powder Coat Finish
Pulse Diaphragm Pump
Easy Use Controls

Weight: 75 lbs (34 kg)
Shipping: Via UPS or Freight



STAINLESS STEEL AUTOMATIC WASH BASIN... Maximize Operator Productivity



POWERCLEAN™ Supply's Compressed Air to the Spray Gun During the Cleaning Process, Protecting the Air Passageways



FLOW BRUSH Stiff Nylon Bristles for Powerful Cleaning

