

# BECCA<sup>®</sup> Options & Accessories

For  
Solvent Saver<sup>™</sup>  
Recyclers

*The  
Professionals  
Choice*

## VACUUM ASSIST SYSTEM

**For All SOLVENT SAVER<sup>™</sup> Models.**

The Vacuum Assist system was designed to reduce the atmospheric pressure in the boiler upto 25" Hg. Vacuum Assist helps the following::

- Increase the differential between the Auto Ignition Temperature and the boiling point of a solvent. This reduces the potential hazard for some solvents during the distillation process.
- Increase the capability of the Recycler to handle solvents with higher boiling points or solvents with high surface tension.
- Improve performance (speed) of the Recycling Process from 10–30%



HC Recycler



SS17.5 Recycler

Vacuum Assist can be used on any Recycler package. Note: Some systems will require a pump transfer kit to move the solvent from the Vacuum Assist tank to another container such as a drum or another clean solvent tank. Contact BECCA for the selection requirements for your system

## BECCA Protect<sup>™</sup> Film

**For all SOLVENT  
SAVER<sup>™</sup> Models**



Before  
Removal

New  
Application of  
BECCA  
Protect<sup>™</sup>



# Recycler/Dual Spray Gun Cleaner Valve Kit

For SOLVENT SAVER™ SC & HC Models

This system provides the capability for a Recycler to handle **two** Spray Gun Cleaners. The function is quite simple. The valve package allows an operator to select between an “A” or “B” Spray Gun Cleaner to unload the “Used” solvent to the recycler.



Any of BECCA's Spray Gun Cleaners can be utilized for the Recycler/Dual Spray Gun Cleaner Valve Kit.

## 5 Gallon Cans or 10 Gallon Tanks

For SC & HC SOLVENT SAVER™ Models

The **5 gal Cans** are standard solvent containers and come equipped with a pour spout.



SC & HC SOLVENT SAVER™ Models

The **10 gal Tanks** are designed for the most demanding operations. Performance features:

- Stainless Steel Construction
- Sight Glass
- Direct Connection



## Tank Transfer Pump Kit

For ALL SOLVENT SAVER™ RECYCLER Models

Some Recycler Systems require the transfer of solvents to and from the unit. We have Transfer Kits available to handle any situation:

- **Pump Transfer Kit - Drum to Recycler** — provides a pump and valve system to control the loading of the Recycler.
- **Pump Transfer Kit - Recycler to Drum** (Only on HC & SC Models) — provides a pump and valve system to control the unloading of the Recycler to another container.



The picture shows a “Clean” solvent pump system on the back of a HC recycler ready to move solvent to another container.



2010 Cobb International Blvd  
Suite H  
Kennesaw, GA 30152  
T 800. 655.5649  
F 800. 655. 5684  
www.beccainc.com  
sales@beccainc.com

For More Information go to [www.beccainc.com](http://www.beccainc.com)