



BECCA® Care

Annual Tune-Up (PM) Maintenance Checklist Spray Gun Cleaners

Questions, Please Contact: **BECCA Inc.**
2010 Cobb International Blvd Ste H OR
Kennesaw, GA 30152

Fax: 800-655-5684
770-419-9438

1) **Customer Name:** _____

2) **Equipment Name and Model (check one):**

Waterborne

Solvent

- E50M Serial #: _____
- E100M Serial #: _____
- E300A Serial #: _____
- E700M Serial #: _____
- E800A Serial #: _____

- S50M Serial #: _____
- S100M Serial #: _____
- S300A Serial #: _____
- S700M Serial #: _____
- S800A Serial #: _____

3) **Maintenance Checklist Review Annual Items**

These items will insure the safety and continued top performance of the equipment

Waterborne Units Only:

To clean all collected paint residues do the following:

- 1) *Flush the System w/ 3 Gallons of Acetone for 1-2 hours.*
- 2) *Pull suction line & let pump run dry for additional ½ hr to vaporize remaining solvent.*

Waterborne & Solvent Units

Manual Features (All Models)

- POWERPISTOL - Check for operation & Leaking
 - Replace w/ Part# 825225
- POWERCLEAN Disconnects – Check for operation
 - Replace w/: Waterborne Systems – Part# 825440 Solvent Systems - Part# 825550
- Splash Pad – If worn out
 - Replace w/:
 - 50 Model Units - Sink Pad w/ Part# 825162 Back Pad w/ Part# 825163
 - 100 Model Units - Sink Pad w/ Part# 825165
 - 700 Model Units - Pan Pad w/ Part# 825159
 - 800 Model Units - Pan Pad w/ Part# 825159
- Flow Brush – Check for operation
 - Replace w/ Part# 824610
- Flow Brush & Coil Hose (300, 700, & 800 Units) – Check for operation
 - Replace w/ Part# 824611K
- Air Pistol - Check for operation
 - Replace w/ Part# 825215
- Foot Pedal - Check for operation
 - Replace w/ Part# 824649

- Exhaust Filter (700 & 800 Units Only) Check for operation
 - Replace w/ Part# 824588K
- 2 – Stage Filter Replacement Kit (700 & 800 Units) - Check for operation
 - Replace Cartridges w/ Part# 824016
 - Replace Kit Assembly w/ Part# 8245013K
- Compressed Air Water Trap (50,100, 300 Units Only) - Check for operation
 - Replace w/ Part# 824010
- Suction Line Strainer - Check for operation
 - Replace w/ Part# 824624
- Pump(s) - Check for operation
 - (Prior to 2005) - Replace w/ Part# 824549R (Rebuilt)
 - (2005 to present) - Replace w/ Part# 811021(New) or Part# 811021R(Rebuilt)

Automatic Features (10, 300, & 800 Models)

- Wash Manifold - Check for operation
 - Replace w/ Part# 825015
- Spray Nozzles - Check for operation
 - Spray Nozzles - Replace w/ Part# 824554
 - Spray Gun Mount Nozzles - Replace w/ Part# 824589
- Spray Gun Clips - Check for operation
 - Replace w/ Part# 825053K

Options

- Heater Systems - Check for operation
 - Heater5 Std Heat - Replace w/ Part# Heater5
 - HeaterEXP - Replace Controller w/ Part# 823211
- Filtration Recycling Systems - Check for operation
 - Filter Kit for Waterborne - Replace w/ Part# 825265K
 - Filter Kit for Solvent - Replace w/ Part# 825244K
- Protect Film –
 - Replace w/ Part# 831004 (200' Roll)

Safety Items (Required when using flammable Solvents)

- Ground Clips for attachment to Containers – Replace w/ Part# 823079K
- Containers (Flammable Solvents Only) capable of grounding – Replace w/ Part# 823200
- Ground Wire for Spray Gun Cleaners – assure ground wire is attached
- General Area is per code – See website for General Arrangement Drawing www.beccainc.com
- All Labels are present and legible- Check for operation
 - Model 50 - Replace w/ Part# 831125K
 - Model 100 - Replace w/ Part# 831125K
 - Model 300 - Replace w/ Part# 831125K
 - Model 700 & 800 - Replace w/ Part# 831128K

4) Operation Review

See Website to review videos on operation of all models www.beccainc.com